


Wiring and Connector Diagrams




BE6373

Ignition Switch




eg-11-2

Hazard Warning Switch




S-10-2

Turn Signal Flasher Relay



BE6241

Turn Signal Switch
(Combination Switch)
Connector "B" Connector "A"



BE6218