


WIRING DIAGRAM



Terminal of ECU

No.	Symbol	Terminal Name	No.	Symbol	Terminal Name
P12-1	SYSB	Power Source	P12-10	PFSW	Reclining Front Limit Switch
2	SLSW	Slide Limit Switch	11	SSRS	Slide Sensor
3	PVCC	Position Sensor Power Source	12	PBCL	Passenger's Buckle Switch
4	DOUT	—	13	RRSW	Reclining Rear Limit Switch
5	SLDR	Slide Switch (Back)	14	CHK	Check
6	SLDF	Slide Switch (Forward)	15	SGND	Sensor Ground
7	SLD+	Slide Motor (Forward)	16	GND	Ground
8	+B	Power Source	17	SLD-	Slide Motor (Back)
9	PRDC	Tension Reducer	18		