


DESCRIPTION

The theft deterrent system uses the door lock control system components and some other parts. When somebody attempts to forcibly enter the vehicle or open the engine hood or luggage compartment door without a key, or when the battery terminals are removed and reconnected, the theft deterrent system sounds the horns and flashes the headlights and taillights for about one minute to alert. At the same time, it locks all the doors and electrically disconnects the starter.

For the function of component parts of this system, refer to the circuit description in circuit inspection.

PARTS LOCATION



PARTS LOCATION (Cont'd)