

MATRIX CHART OF PROBLEM SYMPTOMS

Perform troubleshooting of the circuits for the applicable problem symptom in the order given in the chart below. Proceed to the page located for each circuit.

HINT:

- Troubleshooting of the wireless door lock control system is based on the premise that the door lock control system is operating normally. Accordingly, before troubleshooting the wireless door lock control system, first make certain that the door lock control system is operating normally.
- If the instruction "Proceed to next circuit inspection shown on matrix chart" is given in the flow chart for each circuit, proceed to the circuit with the next highest number in the table to continue the check.
- If the trouble still reappears even though there are no abnormalities in any of the other circuits, then check and replace the Wireless Door Lock ECU as the last step.

See page	BE-44 6	BE-44 8	BE-45 0	BE-45 2	BE-45 4	BE-45 6	IN-32
Suspect Area	ECU Power Source Circuit	Door Unlock Detection Switch Circuit	Door Key Lock and Unlock Switch Circuit (Unlock Side)	Door Key Lock and Unlock Switch Circuit (Lock Side)	Key Unlock Warning Switch Circuit	Door Open Detection Switch Circuit	Wireless Door Lock ECU
Symptom							
All functions of wireless door lock control system do not operate.	1		3	4	5	2	6
Only door unlock operation is not possible (Lock operation is possible).		2	1				3
Only door lock operation is not possible (Unlock operation is possible).				1			2
Only transmitter misoperation prevention function is not possible.					1		2
Wireless door lock function operates even when each door is opened.						1	2
Wireless door lock functions incorrectly. (Although one door is unlocked, when the transmitter switch is pressed, all doors unlock.)		1					2