



LUGGAGE COMPARTMENT Fitting Adjustments



HINT: Adjust the door panel according to the following method.

1. ADJUST LUGGAGE COMPARTMENT

- For forward/rearward and vertical direction adjustments loosen the bolts.
- For left and right adjustment of front end of the door, increase or decrease the number of washers between the hinge and the door.

2. ADJUST LOCK STRIKER

- Remove the trim rear cover.
- Using a hammer and brass bar, tap the door lock to adjust it.

