

Diag. Code 51 ABS Pump Motor Lock

— CIRCUIT DESCRIPTION —

Code No.	Diagnostic Code Detecting Condition	Trouble Area
51	Pump motor is not operating normally during initial check.	•ABS pump motor

Fail safe function: If trouble occurs in the ABS pump motor, the ECU cuts off the current to the motor relay and prohibits ABS control.

— DIAGNOSTIC CHART —

See inspection of ABS pump motor (See page [BR-51](#) or [BR-53](#)).

WIRING DIAGRAM

(Reference)

