

**Diag. Code 54      Excessive Operation of TRAC Pump Motor****— CIRCUIT DESCRIPTION —**

Code No.	Diagnostic Code Detecting Condition	Trouble Area
54	TRAC motor relay ON is output continuously 10 times at intervals of less than 24 sec. when traction control is not being executed.	<ul style="list-style-type: none"><li>•TRAC Actuator</li><li>•Brake fluid leakage</li><li>•ECU</li></ul>

**— DIAGNOSTIC CHART —**