

TRAC Indicator Light Circuit

— CIRCUIT DESCRIPTION —

The TRAC indicator blinks during TRAC operation.

This indicator is also used for warnings when the trouble occurs and for displaying diagnostic codes.


— DIAGNOSTIC CHART —

Perform troubleshooting in accordance with flow chart instructions for each trouble symptom.

TRAC Indicator light does not light up

Go to combination meter troubleshooting on page [BE-146](#).

TRAC Indicator light remains ON



WIRING DIAGRAM

