



VEHICLE LIFT AND SUPPORT LOCATIONS



JACK POSITION

Front Center of suspension crossmember

Rear Jack up support of differential carrier

PANTOGRAPH JACK POSITION

SUPPORT POSITION

Safety stand or swing arm type lift

