

# ADJUSTMENT OF WHEEL BALANCE

## Preparation

### EQUIPMENT

Part Name	Note
Tire pressure gauge	Tire inflation pressre
Wheel balancer	Wheel balance
Dial indicator	Wheel runout