

## STEERING COLUMN


### Description

All vehicles are equipped with the highly convenient power tilt/power telescopic steering column.

### Operation


#### POWER TILT OPERATION

The power tilt mechanism consists of the control gear assembly, tilt motor, tilt position sensor, tilt and telescopic switch, unlock warning switch and tilt and telescopic ECU.




N00804

The control gear assembly consists of the worm wheel, tilt gear, tilt worm and slider. Rotation of the tilt motor moves the slider towards the tilt worm. The column upper tube is integrated with the slider and is rotated up and down by movement of the slider.



SR3437



SR3438