







## PREPARATION

### SST (SPECIAL SERVICE TOOLS)

Illustration	Part No.	Part Name	Note
	09201-41020	Valve Stem Oil Seal Replacer	Armature rear bearing
	09286-46011	Injection Pump Spline Shaft Puller	Armature front bearing
	09612-24014	Steering Gear Housing Overhaul Tool Set	
	(09617-24011)	(Steering Rack Wrench)	Fuel Inlet hose
	09950-00020	Bearing Remover	Armature rear bearing

### RECOMMENDED TOOLS

Illustration	Part No.	Part Name	Note
	09082-00015	TOYOTA Electrical Tester	

### EQUIPMENT

Part Name	Note
Dial indicator	Commutator
Vernier caliper	Commutator, Brush
Pull scale	Brush spring
Torque wrench	