


AIR CONDITIONING CONTROL ASSEMBLY REMOVAL

AC14U-02

1. REMOVE RADIO WITH A/C CONTROL ASSEMBLY
(See page [BO-95](#))



2. REMOVE A/C CONTROL ASSEMBLY
Remove the 4 screws and the A/C control assembly.