

INSPECTION

1. INSPECT ROOM TEMPERATURE SENSOR
(See page DI-823)
2. INSPECT AMBIENT TEMPERATURE SENSOR
(See page DI-826)
3. INSPECT SOLAR SENSOR
(See page DI-835)
4. INSPECT EVAPORATOR TEMPERATURE SENSOR
(See page DI-829)
5. INSPECT REVOLUTION DETECTING SENSOR
(See page DI-838)
6. INSPECT ENGINE COOLANT TEMPERATURE SENSOR
(See page DI-832)