



DISASSEMBLY

1. REMOVE WIRE HARNESS

- (a) Remove the 6 screws and clips.
- (b) Disconnect the connectors and remove the wire harness from the instrument panel.

2. REMOVE THESE PARTS:

- (a) Defroster nozzle
- (b) No. 1 heater to register duct
- (c) No. 5 heater to register duct
- (d) Air duct No. 1 retainer
- (e) Register No. 1
- (f) Glove compartment door lock control cable
- (g) Instrument panel garnish
- (h) Defroster nozzle garnish No. 1
- (i) Defroster nozzle garnish No. 2
- (j) Solar sensor
- (k) Automatic light control sensor