

INSTALLATION

Installation is in the reverse order of removal (See page [BR-48](#)).

AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)) AND CHECK FOR LEAKS