

INSTALLATION

Installation is in the reverse order of removal (See page [BR-10](#)).

1. BEFORE INSTALLATION, ADJUST LENGTH OF BRAKE BOOSTER PUSH ROD
(See page [BR-19](#))
2. AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)), CHECK FOR LEAKS
3. CHECK AND ADJUST BRAKE PEDAL (See page [BR-6](#))