

INSTALLATION

Installation is in the reverse order of removal (See page [BR-24](#)).

AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)) AND CHECK FOR LEAKS

NOTICE:

These should be no oil or grease adhering to the friction surfaces of the pads or disc.