

INSTALLATION

Installation is in the reverse order of removal (See page [CL-5](#)).

HINT:

After installation, adjust the clutch pedal and bleed the clutch system.