

INSTALLATION

Installation is in the reverse order of removal (See page [CL-10](#)).

HINT:

After installation, bleed the clutch system.