

AUTOMATIC TRANSMISSION (1UZ-FE)

HOW TO PROCEED WITH TROUBLESHOOTING

DI45M-01

Troubleshoot in accordance with the procedure on the following pages.

