

DTC	P0101	Mass Air Flow Circuit Range / Performance Problem
------------	--------------	--

CIRCUIT DESCRIPTION

Refer to Mass Air Flow Circuit Malfunction on page [DI-172](#).

DTC No.	DTC Detecting Condition	Trouble Area
P0101	Conditions (a) and (b) continue with engine speed 900 rpm or less: (2 trip detection logic) (a) Closed throttle position switch: ON (b) Mass air flow meter output > 2.2 V	<ul style="list-style-type: none"> • Mass air flow meter

WIRING DIAGRAM

Refer to Mass Air Flow Circuit Malfunction on page [DI-172](#).

INSPECTION PROCEDURE

1	Are there any other codes (besides DTC P0101) being output?
----------	--

YES

Go to relevant DTC chart.

NO

Replace mass air flow meter.