

POWER SEAT CONTROL SYSTEM (Driver)

HOW TO PROCEED WITH TROUBLESHOOTING

DI48V-01

Perform troubleshooting in accordance with the procedure on the following page.

