

EQUIPMENT

| | |
|-----------------------|---|
| Bulb (2.1 W) | Turn signal flasher relay |
| Bulb (3.4 W) | Fuel sender gauge, Seat belt warning relay |
| Clip remover | For removing cowl louver |
| Dry cell battery | Fuel sender gauge |
| Heat light | Seat heater |
| Hexagon wrench (6 mm) | Power seat |
| Masking tape | Rear window defogger wire |
| Oil bath | Engine oil level warning switch |
| Syphon | Brake fluid level warning switch |
| Test lead | |
| Thermometer | Engine coolant temp. sender gauge Engine oil level warning switch, Seat heater |
| Tin foil | Rear window defogger wire |
| Torque wrench | |