


























SUSPENSION AND AXLE














SST (Special Service Tools)

PP2VE-01














	09223-00010	Cover & Seal Replacer	Front suspension
	09223-15020	Oil Seal & Bearing Replacer	Rear axle
	09223-46011	Crankshaft Front Oil Seal Replacer	Differential
	09229-55010	Oil Cooler Relief Valve Wrench	Differential
	09240-00020	Wire Gauge Set	Drive shaft
	09250-10011	Replacer Set "A"	
	(09252-10010)	No. 1 Replacer Handle-	Differential
	(09255-10011)	Crankshaft Rear Bearing Remover & Replacer	Differential
	09308-00010	Oil Seal Puller	Front axle Rear axle Differential
	09309-36010	Transmission Rear Bearing Replacer	Rear axle Drive shaft
	09316-12010	Transfer Bearing Replacer	Differential
	09316-60011	Transmission & Transfer Bearing Replacer	


PREPARATION — SUSPENSION AND AXLE

	(09316-00011) Replacer Pipe	Differential
	(09316-00041) Replacer "C"	Differential
	09325-40010 Transmission Oil Plug	Differential
	09330-00021 Companion Flange Holding Tool	Differential
	09502-12010 Differential Bearing Replacer	Drive shaft Differential
	09502-24010 Bearing Replacer	Differential
	09520-00031 Rear Axle Shaft Puller	Rear axle
	09520-24010 Differential Side Gear Shaft Puller	Differential
	09521-24010 Drive Shaft Boot Clamping Tool	Drive shaft
	09570-24010 Differential Mounting Cushion Remover & Replacer	Differential
	09608-06041 Front Hub Inner Bearing Cone Replacer	Front axle
	09608-30012 Front Hub & Drive Pinion Bearing Tool Set—	Differential
	09608-32010 Steering Knuckle Oil Seal Replacer	Front axle Rear axle Differential

	09610-20012 Pitman Arm Puller	Rear suspension
	09628-10011 Ball Joint Puller	Front axle Hub bolt Rear suspension
	09628-62011 Ball Joint Puller	Front axle Front suspension Rear axle Rear suspension
	09710-14013 Rear Suspension Bushing Tool Set	Front suspension
	(09710-00021) Pipe	
	09710-30021 Suspension Bushing Tool Set	Rear suspension
	(09710-03111) Bushing Remover	
	(09710-03121) Bushing Remover Base	
	09710-30050 Suspension Arm Bushing Replacer	Differential
	09726-12023 Lower Suspension Arm Bushing Remover & Replacer	Drive shaft
	(09726-01031) Spacer	
	09727-30021 Coil Spring Compressor	Front suspension Rear suspension
	09950-00020 Bearing Remover	Differential

PREPARATION – SUSPENSION AND AXLE

	09950-60010 Replacer Set	
	(09951-00420) Replacer 42	Rear axle
	(09951-00450) Replacer 45	Differential
	(09951-00510) Replacer 51	Differential
	(09951-00560) Replacer 56	Front axle Rear axle
	09950-60020 Replacer Set No.2	
	(09951-00710) Replacer 71	Differential
	(09951-00720) Replacer 72	Front axle
	(09951-00780) Replacer 78	Differential
	(09951-00810) Replacer 81	Differential
	(09951-00890) Replacer 89	Differential
	(09951-01030) Replacer 103	Rear axle
	09950-70010 Handle Set	

	(09951-07150) Handle 150	Rear axle Differential
---	--------------------------	---------------------------