



## INSPECTION

### 1. VEHICLE NOT INVOLVED IN A COLLISION

Do a diagnostic system check. (See page [DI-540](#))

### 2. VEHICLE INVOLVED IN A COLLISION AND AIRBAG IS NOT DEPLOYED

Do a diagnostic system check. (See page [DI-540](#))

### 3. VEHICLE INVOLVED IN COLLISION AND AIRBAG IS DEPLOYED

Replace the airbag sensor assembly.