


REPLACEMENT

1. REMOVE BUSHING

Using SST and a deep socket wrench, remove the bushing.

SST 09710-14013 (09710-00021)



2. INSTALL NEW BUSHING

Using SST and a deep socket wrench, install a new bushing.

SST 09710-14013 (09710-00021)

NOTICE:

Do not apply grease or oil to the bushing.