



## INSTALLATION

### 1. INSTALL FUEL PRESSURE PULSATION DAMPER

Using SST, install 2 new gaskets, the inlet hose and pulsation damper.

SST 09612-24014 (09617-24011)

**Torque:**

**39 N·m (400 kgf·cm, 29 ft·lbf)**

**33 N·m (340 kgf·cm, 24 ft·lbf) for use with SST**

**HINT:**

Use a torque wrench with a fulcrum length of 30 cm (11.81 in.).

### 2. INSTALL V-BANK COVER