



**SC400:****SC300:**

## AIR CONTROL VALVE INSPECTION

SR0GP-02

1. TURN AIR CONDITIONER SWITCH OFF
2. **SC 400:**  
REMOVE V-BANK COVER
3. **CHECK IDLE-UP**
  - (a) Start the engine and run it at idle.
  - (b) Fully turn the steering wheel.
  - (c) Check that the engine rpm decreases when the air control valve hose is pinched.
  - (d) Check that the engine speed increases when the hose is released.