

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
Transmission output flange x Output shaft		126	1,280	93
Solenoid connector set bolt		5.4	55	48 in.·lbf
Solenoid wiring clamp set bolt		5.4	55	48 in.·lbf
Oil strainer x Valve body		10	100	7
Oil pan x Transmission case		7.4	75	65 in.·lbf
Drain plug		20	205	15
Shift solenoid valve No.1, No.3, SLU and SLT set bolt		6.4	65	56 in.·lbf
Shift solenoid valve No.2, No.4 and SLN set bolt		10	100	7
Valve body x Transmission case		10	100	7
Heated oxygen sensor x Front exhaust pipe		44	450	32
Front exhaust pipe x Front TWC		43	440	32
Pipe support bracket x Transmission		43	440	32
Front exhaust pipe x Center exhaust pipe		43	440	32
Front TWC x Exhaust manifold		62	630	46
Heat insulator x Body		5.4	55	48 in.·lbf
Center floor crossmember brace x Body		13	130	9
Shift control rod x Shift lever		13	130	9
Oil cooler pipe union nut		44	450	32
Oil cooler pipe clamp set bolt		4.9	50	43 in.·lbf
Torque converter clutch x Drive plate		48	490	35
Engine rear mounting x Body		25	260	19
Flywheel housing under cover set bolt		18	185	13
Transmission x Engine	14 mm head	37	380	27
	17 mm head	72	730	53
Drive plate x Crankshaft		83	850	61
Vehicle speed sensor x Extension housing		5.4	55	48 in.·lbf
Park/Neutral Position Switch x Transmission case	Bolt	5.4	55	48 in.·lbf
	Nut	6.9	70	61 in.·lbf
Control shaft lever x Manual valve lever shaft		16	160	12
Propeller Shaft x Transmission		79	805	58
Propeller Shaft x Rear differential		79	805	58
Center Support bearing x Body		49	500	36
Front stabilizer bar link x Front stabilizer bar		74	750	54
Front shock absorber x Front lower suspension arm		143	1,460	106
Front lower ball joint x Steering knuckle		125	1,270	92
Front lower suspension arm bracket stay	Bolt	43	440	32
	Nut	59	600	43
Front lower suspension arm x Frame		226	2,260	116
Upper front crossmember extension	Bolt	29	300	22
	Nut	33	340	25
Front suspension member x Body		200	2,050	148