

Vehicle Wiring Information

for the

1997 Lexus SC 400

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white & white/red	+	ignition harness
STARTER	black/red	+	ignition harness
IGNITION	black/white	+	ignition harness
SECOND IGNITION	black/yellow	+	ignition harness
ACCESSORY	red	+	ignition harness
POWER LOCK	green/yellow	-	passenger kick panel
POWER UNLOCK	green/white	-	passenger kick panel
PARKING LIGHTS +	green		drivers running board
PARKING LIGHTS -	green		steering column
HEADLIGHTS	red/green	-	steering column
DOOR TRIGGER	red/white	-	drivers kick panel
TRUNK/HATCH PIN	red/white/silver dot	-	drivers running board
HOOD PIN	grn/blu or grn/org	-	hood switch
TRNK/HTCH RELEASE	blue	-	switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	disarms with unlock		
DISARM NO UNLOCK	green	-	drivers kick panel
TACHOMETER	black		ignitor *1
BRAKE WIRE	green/white	+	brake pedal switch or dkp
HORN TRIGGER	green/red	-	steering column
WIPERS	blu/red(L),red/blu(H)	+	steering column
LF WINDOW UP/DN	red - grn/yel	A	drivers door switch
RF WINDOW UP/DN	red/blu - grn/wht	A	drivers switch or kick panel

Notes:

*1 Ignitor is on the driver side of the engine compartment next to the shock tower. Also found at the diagnostic connector under the hood.

(c) 1994-2002 Directed Electronics, Inc. All Rights Reserved

IMPORTANT: This wiring information is being provided free of charge on an "as is" basis, without any representation or warranty. It is your responsibility to verify any circuit before interfacing with it using a digital multimeter.

Directed Electronics, Inc. assumes no responsibility with regards to the accuracy or currency of this information. Proper installation in every case is and remains the responsibility of the installer.

DEI assumes no liability or responsibility resulting from an improper installation, even in reliance upon this information.