WIRE HARNESS AND CONNECTOR

RS084–03

LOCATION