


SYSTEM OUTLINE

With the ignition SW turned on, the current flows to TERMINAL 17 of the front wiper and washer SW, and TERMINAL 2 of the front wiper motor through the WIPER fuse, TERMINAL 2 of washer motor through the WASHER fuse.

1. LOW SPEED POSITION

With wiper SW turned to LO position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the front wiper motor to TERMINAL 4 to GROUND and causes the front wiper motor to run at low speed.

2. HIGH SPEED POSITION

With wiper SW turned to HI position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 8 to TERMINAL 3 of the front wiper motor to TERMINAL 4 to GROUND and causes the front wiper motor to run at high speed.

3. INT POSITION

With wiper SW turned to INT position, the relay operates and the current which is connected by relay function flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 2 to GROUND. This flow of current operates the intermittent circuit and the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the front wiper motor to TERMINAL 4 to GROUND and operates the wiper.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW to change the charging time of the condenser.

4. MIST POSITION

With wiper SW turn MIST position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the wiper motor to TERMINAL 4 to GROUND and causes the wiper motor to run at low speed.

5. WASHER CONTINUOUS OPERATION

With washer SW turned to on, the current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 11 of the front wiper and washer SW to TERMINAL 2 to GROUND and causes to the washer motor to run, and the window washer emits a water spray. This causes the current to flow to washer continuous operation circuit in TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 5 of the front wiper motor to TERMINAL 4 to GROUND and operates the wiper.

SERVICE HINTS

C17 FRONT WIPER AND WASHER SW [COMB. SW]

2-GROUND : Always continuity

17-GROUND : Approx. 12 volts with the ignition SW at **ON** or **ST** position

7-GROUND : Approx. 12 volts with the front wiper and washer SW at **LO** position

Approx. 12 volts 2 to 12 seconds intermittently with the front wiper and washer SW at **INT** position

16-GROUND : Approx. 12 volts with the ignition SW on unless the front wiper motor at **STOP** position

8-GROUND : Approx. 12 volts with the front wiper and washer SW at **HI** position

F7 FRONT WIPER MOTOR

2-1 : Closed unless the wiper motor at **STOP** position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	A	42	F7	40 (2JZ-GE)	W1
C13	B	42	J6	43	
C17		42	J10	43	W2
F7		38 (3UZ-FE)	J12	43	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	28	Cowl Wire and Driver Side J/B (Left Kick Panel)
1D	28	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F	28	Cowl Wire and Driver Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	52	Cowl Wire and Cowl Wire (Left Side of the Instrument Panel Reinforcement)
IE1	52	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)

WIPER AND WASHER



: GROUND POINTS

Code	See Page	Ground Points Location
EB	48 (3UZ-FE)	Left Fender
	50 (2JZ-GE)	
IF	52	Left Kick Panel
IG	52	Left Side of the Cowl Panel

