

PROBLEM SYMPTOMS CHART

If a normal code is displayed during the diagnostic code check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the page for troubleshooting.

Symptoms	Inspection Circuit	See page
ABS does not operate.	<ol style="list-style-type: none"> 1. Check the diagnostic code, reconfirming that the normal code is output. 2. IG Power Source Circuit. 3. Speed sensor circuit. 4. Check the ABS actuator with a checker. If abnormal, check the hydraulic circuit for leakage (see page BR-138). <p>If 1. ~ 4. are all normal and the problem is still occurring, replace the ABS (& TRAC) ECU.</p>	BR-62 BR-114 BR-110 BR-50 or 53
ABS does not operate efficiently.	<ol style="list-style-type: none"> 1. Check the diagnostic code, reconfirming that the normal code is output. 2. Speed sensor circuit. 3. Stop light switch circuit. 4. Check the ABS actuator with a checker. If abnormal, check the hydraulic circuit for leakage (see page BR-138). <p>If 1. ~ 4. are all normal and the problem is still occurring, replace the ABS (& TRAC) ECU.</p>	BR-62 BR-110 BR-128 BR-50 or 53
ABS warning light abnormal.	<ol style="list-style-type: none"> 1. ABS warning light circuit. 2. ABS (& TRAC) ECU. 	BR-130
Diagnostic code check cannot be performed.	<ol style="list-style-type: none"> 1. ABS warning light circuit. 2. Tc terminal circuit. 3. ABS (& TRAC) ECU. 	BR-130 BR-134
Speed sensor signal check cannot be performed.	<ol style="list-style-type: none"> 1. Ts terminal circuit. 2. ABS (& TRAC) ECU. 	BR-136