

AUTOMATIC SHIFT SCHEDULE

SHIFT POINT

Shift range	Kick-down Foot switch	Pattern select switch	Throttle valve fully open [fully closed] km/h (mph)							
			1 2	2 3	3 O/D	[3 O/D]	[O/D 3]	O/D 3	3 2	2 1
D range	ON	NORM	67-71 (42-44)	118-124 (73-77)	170-177 (106-110)	-	-	164-170 (102-106)	105-111 (65-69)	53-57 (33-35)
		PWR	67-71 (42-44)	118-124 (73-77)	179-186 (111-116)	-	-	164-170 (102-106)	105-111 (65-69)	53-57 (33-35)
	OFF	NORM	67-71 (42-44)	118-124 (73-77)	155-161 (96-100)	[32-35] [(20-22)]	[23-26] [(14-16)]	128-134 (79-83)	71-75 (44-47)	10-13 (6-8)
		PWR	67-71 (42-44)	118-124 (73-77)	179-186 (111-116)	[32-35] [(20-22)]	[23-26] [(14-16)]	149-155 (93-96)	95-100 (59-62)	22-26 (14-16)
2 range	ON	NORM or PWR	67-71 (42-44)	-	-	-	-	-	106-112 (66-70)	53-57 (33-35)
	OFF	NORM or PWR	67-71 (42-44)	-	-	-	-	-	106-112 (66-70)	10-13 (6-8)
L range	ON OFF	NORM or PWR	-	-	-	-	-	-	104-109 (65-68)	57-63 (35-39)

LOCKUP POINT

Shift range	Pattern select switch	Throttle valve opening 5 % km/h (mph)			
		Lockup ON		Lockup OFF	
		*3rd	O/D	*3rd	O/D
D range	NORM or PWR	83-88 (52-55)	56-60 (35-37)	77-82 (48-51)	53-57 (33-35)

* O/D Switch OFF

- HINT:
- (1) There is no lockup in the 2 and L ranges.
 - (2) In the following cases, the lock-up will be released regardless of the lockup pattern.
 - When the throttle valve is completely closed.
 - When the brake light switch is ON.
 - (3) Shift up to 3rd will not occur when the engine coolant temp. is below 355C (955F) and the vehicle speed is below 40 km/h (25 mph).
 - (4) Shift up to O/D will not occur when the engine coolant temp. is below 605C (1405F) and the vehicle speed is below 60 km/h (37 mph).
 - (5) During cruise control operation, the shift pattern is fixed in NORM. And when the vehicle speed drops to 10 km/h (6 mph) or more below the cruise control set vehicle speed, shift down from O/D to 3rd occurs.
 - (6) The kick-down foot switch turns ON when the accelerator pedal is depressed further with the throttle valve already fully open.