


* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

HOW TO READ THIS SECTION



[A] : System Title


[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black W = White BR = Brown
 L = Blue V = Violet SB = Sky Blue
 R = Red O = Orange LG = Light Green
 P = Pink Y = Yellow GR = Gray
 G = Green

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.


Example: L – Y



[C] : The position of the parts is the same as shown in the wiring diagram and wire routing.


[D] : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right



Female

Numbered in order from upper right to lower left



Male


The numbering system for the overall wiring diagram is the same as above

[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : ① Indicates Relay Block No.1


[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



[G] : Indicates related system.

[H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗). Outside numerals are pin numbers.



[I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[J] : Indicates a shielded cable.



[K] : Indicates and located on ground point.

[L] : The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
Auto Antenna	18-2	Multiplex Communication System	1-2
Automatic Air Conditioning	29-2	* Automatic Light Control	
Automatic Glare-Resistant EC Mirror	21-2	* Garage Door Opener	
Back-Up Light	10-2	* Interior Light	
Cellular Mobile Telephone	23-2	* Key Reminder and Seat Belt Warning	
Charging	3-4	* Light Auto Turn Off	
Cigarette Lighter and Power Outlet	18-3	* Luggage Compartment Door Opener	
Clock	18-4	* Power Seat (Driver's Seat w/ Driving Position Memory)	
Combination Meter	28-2	* Power Window	
Cruise Control (3UZ-FE)	14-2	* Remote Control Mirror	
Cruise Control (2JZ-GE)	15-2	* Theft Deterrent and Door Lock Control	
Electric Tension Reducer	18-2	* Wireless Door Lock Control	
Electronically Controlled Transmission and A/T Indicator (3UZ-FE)	12-2	Power Seat (Driver's Seat w/o Driving Position Memory)	22-2
Electronically Controlled Transmission and A/T Indicator (2JZ-GE)	13-2	Power Seat (Front Passenger's Seat)	22-3
Engine Control and Engine Immobiliser System (3UZ-FE)	4-2	Power Source	1~30-1
Engine Control and Engine Immobiliser System (2JZ-GE)	5-2	Power Tilt and Power Telescopic	20-4
Fog Light	6-2	PPS	24-1
Fuel Lid Opener	18-4	Radiator Fan and Condenser Fan	30-2
Headlight	7-2	Radio and Player (MARK LEVINSON)	26-2
Headlight Beam Level Control	11-2	Radio and Player (Except MARK LEVINSON)	27-2
Headlight Cleaner	11-4	Rear Window Defogger and Mirror Heater	24-3
Horn	19-4	Seat Heater	21-4
Illumination	9-2	Shift Lock	6-3
LEXUS Navigation System	25-2	SRS	17-2
Moon Roof	20-2	Starting and Ignition (3UZ-FE)	2-2
		Starting and Ignition (2JZ-GE)	3-2
		Taillight and Stop Light	8-2
		Turn Signal and Hazard Warning Light	10-3
		VSC	16-2
		Wiper and Washer	19-2