

<b>DTC</b>	<b>P1520</b>	<b>Stop Light Switch Signal Malfunction</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

The purpose of this circuit is to prevent the engine from stalling, while driving in lock-up condition, when brakes are suddenly applied.

When the brake pedal is depressed, this switch sends a signal to ECM. Then the ECM cancels operation of the lock-up clutch while braking is in progress.

DTC No.	DTC Detecting Condition	Trouble Area
P1520	The stop light switch does not turn off even once the vehicle is driven (2-trip detection logic).	<ul style="list-style-type: none"> <li>• Short in stop light switch signal circuit</li> <li>• Stop light switch</li> <li>• ECM</li> </ul>

## WIRING DIAGRAM

See page [DI-143](#).

## INSPECTION PROCEDURE

See page [DI-143](#).