

DTC	P1346	VVT Sensor/Camshaft Position Sensor Circuit Range/Performance Problem (Bank 1)
------------	--------------	---

CIRCUIT DESCRIPTION

Refer to DTCs P0335 and P0340 on pages [DI-72](#) and [DI-74](#).

DTC No.	DTC Detecting Condition	Trouble Area
P1346	Deviation in crankshaft position sensor signal and camshaft position sensor signal (2 trip detection logic)	<ul style="list-style-type: none"> • Mechanical system (Jumping teeth of timing belt, belt stretched) • ECM

WIRING DIAGRAM

Refer to DTC P0335 on page [DI-72](#).

INSPECTION PROCEDURE

HINT:

Read freeze frame data using LEXUS hand-held tester or OBD II scan tool. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1	Check valve timing (Check for loose and jumping teeth of timing belt).
----------	---

NG

Adjust valve timing (Repair or replace timing belt).

OK

Check and replace ECM (See page [IN-32](#)).